



## The new 5/2 Way Pneumaticvalve (J-Valve)

Schwarzwaldstr.8 D-79219 Staufen Tel.:+49 (0)7633-7937 Fax.:+49(0)7633-81649 www.jet-tronics.de E-mail:horst.lenerz@t-online.de

This valve is attached directly to the receiver to control undercarriages with double acting zylinders. It replaces the mechanical valve AND the servo plus linkage:

- The bottom measurements without connections aren't greater than a usual mechanical valve (L = 34 mm, B = 28 mm) in which the room is dropped for servo and linkage. The height is 29 mm.
- The connections consist of high-quality metal fast connections for tubes with 3 mm of outside diameter.
- The speed of delivering in and out of the undercarriage can be throttled. This happens by using restrictors which are attached at output 3.
- In the off condition both valves are closed while only one of the valves is open when operating, dependently on the position of the transmitter function.
- The remember function prevents that the undercarriage unintentionally works, if the transmitter function should be in a other position as on shutdown.
- The current consumption of 100 mA at 5 volts is by 50% lower than at the usual 1 watt valves. •
- Viton sealings make the valve insensitive toward most oil sorts.
- The air throughput is around 40% higher and therefore very well suitable also for big undercarriages.

## Adjusting the switching point is rather simple:

- Switch on transmitter/receiver.
  Transmitter function to undercarriage "IN".
  Press button of the valve which has to be "ON" to deliver undercarriage. (this is dependent on the connections to the undercarriage cylinders)
- 4. Transmitter function on undercarriage "OUT".
- 5. Press other button and wait 2 seconds.

The learned switching points remain saved also after turning the receiver power off.

Technical data:	
Supply voltage	3,5V7.5V
Current consumption	100mA bei 5V
Pressure range	0 – 10 Bar
Measurements	34x28x29 mm L/B/H
Weight	55 gr
Connection:	3mm fast connectors (4mm possible if wanted)

Remark: The noise which the valve produces arises from current reduction and is normal



## Tronics

## Connection diagram Anschlußschema

